

## 4m - ECONOMY




**Step1.** Assembly is easiest if you layout all parts on the ground as shown below. 2 meter per section 4x6m has 3 sections, Assemble the roof frame by mounting parts 4 and 5 on the pipes (parts 1, 2). Use the bolts(12) to attach the parts. Let op: *De stokken aangeduid met nr 1 zijn iets langer dan de No 2 stokken. 3 stikken met No 2 zijn ingekort!!* 



**Step2.** Lift one side of the tent frame and attach the legs (3). Place the roof (15) onto the frame and use the long


bungees (9) to fasten it.

Be sure not to put too much tension on the bungees in order not to make attaching the other side more difficult



**Step 3.** Attach the legs on the other side. Make sure, that the leg pipes are in vertical position, to avoid overtention

on the end walls. Use the long ground pegs (7) to fasten the feet to the ground. Attach the side covers to the pipes (4) using hooks (13).




**Step 4.** Unfold the side walls (16) and the end walls (17) and attach the side walls to the frame using the bungees (9).

Attach the end walls directly to the roof using the short bungees (10).

Use the short ground pegs (8) to fasten the end walls to the ground. The guy rope runs from every corner of the tent

and is braced to the ground using the spiral pegs(6).



Contents - Inhoud - Inhalt					
Artikel Nr.	Description	ID Nummer		4x4m	4x6m
	- 1		0		
1	Tube 2060mm			6	8
2	Tube 1930mm			6	9
3	Leg Tube 2080mm	3	(1 ****)	6	8
4	3 -way connector	4	7	6	6
5	4 -way connector		4	3	6
6	Foot Base		J	6	8
7	Screw		© <del></del>	36	50
8	Hook		<b>∠</b> ✓	6	8
9	Bungee ball Small		9	24	24
10	Bunge ball Big		9	76	98
11	Roof			1	1
12	Side wall			4	6
13	End Wall			2	2
14	Big Peg		4	4	4
15	Middle Peg		. ф6	6	8
16	Small Peg		φ4.4	24	32
17	Rope			4	4